



Austrian Gas Grid Management AG


# Dashboard

AGGM Platform

- ▶ AGGM offers a dashboard for users in the login area on the AGGM platform. Depending on the role of the user, different widgets can be selected.
  
- ▶ The dashboard offers the following functions:
  - ▶ add new widgets
  - ▶ remove widgets
  - ▶ show more details
  - ▶ move widgets

- ▶ The "Add Widget" button opens a dialog box and the widget can be selected according to the role and added to your own dashboard.
- ▶ The widgets are used to:
  - ▶ display selected time series
  - ▶ to create an overview of balance groups and their child elements
  - ▶ Download of selected XML-files
- ▶ Any number of widgets can be added. A delete function allows you to remove selected widgets.

- ▶ The "Add widget" button can be used to create a new widget.
- ▶ After clicking this button, the "Add widget" menu opens. In this menu it is possible to select different types of widgets.




The "Add widget" dialog box is shown. It features a dropdown menu labeled "Widget \*" with a downward arrow. Below the dropdown are two buttons: "Cancel" and "Add widget".


The "Add widget" dialog box is shown with the dropdown menu open. The menu lists the following options:

- E/X-Point
- Timeseries
- Master Data XML
- BG-Administration


- ▶ The red dustbin button enables the user to remove added widgets.
- ▶ After clicking this button, the selected widget is removed.



- ▶ The "i" button enables the user to get more information on the current widget.
- ▶ This feature is only available for the E/X Point widget.



- ▶ With the "six point" button it is possible to move the widget around.
- ▶ It is possible to exchange positions between each individual widget with this feature.




# What widgets are available?

Not all widgets are available to all users. The table below shows which widgets are available to which users.


| Widget            | BGR | supplier | distribution system operator |
|-------------------|-----|----------|------------------------------|
| E/X-Point         | X   | X        | X                            |
| Timeseries        | X   | X        | X                            |
| Master Data XML   |     |          | X                            |
| BG-Administration | X   |          |                              |



- ▶ This widget is used to display a time series from the data monitor on the current gas day.
- ▶ The same time series from the data monitor are offered for selection
- ▶ This widget is available for all users in the login area.
- ▶ With the "Show details" button you can navigate directly to the data monitor.



- ▶ This widget displays the timeseries of an Entry/Exit point of the Austrian map on the current gas day.
- ▶ When selecting the widget, the E/X point, as well as the timeseries (Allocation, Capacity booked, Capacity nomination, Capacity re nomination, Physical flow) can be selected via checkbox.
- ▶ This widget is available for all users in the login area.
- ▶ With "Show details" you can navigate directly to the data monitor.



- ▶ This widget is used to provide an overview of the balance group portfolio.
- ▶ The Y-code and the validity of the balance groups are displayed.
- ▶ This widget displays the number of balance group members and supplier accounts.
- ▶ With "Show details" you can navigate directly to the BG-Administration and BG-Assignment.
- ▶ This module is only available to balance group responsible parties.

|                                   |   |                              |
|-----------------------------------|---|------------------------------|
| <b>BG</b>                         |   |                              |
| Validity: 01/01/4000 - 31/12/4000 |   |                              |
| BG-Member:                        | 1 | <a href="#">Show details</a> |
| SA:                               | 0 | <a href="#">Show details</a> |

- ▶ This widget offers the direct download of master data XML.
- ▶ With "Show details" it is possible to navigate directly to the Operator interface.
- ▶ This widget is only available for network operators.

